
Power Measuring

CLAMP ON POWER HITESTER 3286-20



All powerful ! Easy operation ! **True-RMS Clamp-on Power Meter!**

- •Use as a single-phase power meter or power factor meter (3kW to 600kW range)
- Simple checking of three-phase lines (6kW to 1200kW range)
- Check power supply fluctuations
- 1000 A, 1000 Hz, peak and harmonic measurement
- True RMS (effective value) display method



Basic specifications

Order Code

3286-20

Measurement lines	Single-phase/two-wires, Three-phase/three-wires (balanced load only)
	Voltage, current, voltage/current peak, effective/reactive/apparent power(Single-
Measurement items	phase or 3-phase), power factor, reactivity, phase angle, frequency, phase
	detection(3-phase), voltage/current harmonic levels(up to 20th)
	Voltage: 150.0 V to 600 V, 3 ranges, Current: 20.00 to 1000 A, 3 ranges,
Measurement ranges	Power: 3.000 kW to 1200 kW, 18 combination patterns,
	Note: 3-phase power is calculated and displayed on the basis of a balanced, 50/60 Hz, sine wave input. For apparent power and reactive power, the unit of watts in the above table is replaced by VA and var respectively.
	Power/single-phase: ±2.3 % rdg. ±5 dgt., Power/3-phase: ±3.0 % rdg.
Basic accuracy	±10 dgt. (at balanced load)
at 50/60 Hz, cos φ=1	Voltage: ±1.0 % rdg. ±3 dgt. (True RMS), Current: ±1.3 % rdg. ±3 dgt.
	(True RMS)
Frequency	AC current : 45 to 1 kHz
characteristics	AC voltage : 30 to 1 kHz
Other functions	Phase detection, Record (Max. value/Min. value), Battery capacity
	display, Data hold, Auto power off

Accessories

 \triangle **WARNING** Inspect the unit and check that it is operating correctly before use. When

carrying out measurement on live lines, wear proper protective gear, insulating rubber gloves, insulating rubber boots and safety helmet, and use extreme caution to avoid electric shock accidents.

All information correct as of Dec. 27, 2016. All specifications are subject to change without notice.

VOLTAGE CORD L9635-01 ×1 CARRYING CASE 9245 ×1 Hand strap ×1 Instruction manual ×1 Stacked alkaline battery (6LF22) × 1

> A DANGER In order to prevent short-circuits and injury, use the clamp product on electrical circuits with a voltage less than the maximum operation circuit oltage.



HIOKI E.E. CORPORATION

HEADQUARTERS

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 FAX +81-268-28-0568 http://www.hioki.com / E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION

TEL +1-609-409-9109 FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com

HIOKI (Shanghai) SALES & TRADING CO., LTD. TEL +86-21-63910090 FAX +86-21-63910360 http://www.hioki.cn / E-mail: info@hioki.com.cn

HIOKI SINGAPORE PTE. LTD. TEL +65-6634-7677 FAX +65-6634-7477 E-mail: info-sg@hioki.com.sg



HIOKI KOREA CO., LTD.

TEL +82-2-2183-8847 FAX +82-2-2183-3360 E-mail: info-kr@hioki.co.jp

Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies. DISTRIBUTED BY

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HIOKI E.E. CORPORATION is under license.